HarmonicPlanetary® HPN Value Series

5 Sizes

Size

11, 14, 20, 32, 40

 $9 \mathrm{Nm} \sim 752 \mathrm{Nm}$

Backlash

Up to 97%

Peak Torque

Reduction Ratio

High Efficiency

Output Bearing

maximizing tilting moment capacity.

Single stage: 3:1 to 10:1, Two stage: 15:1 to 50:1

Single stage: < 5 arc-min, Two stage: < 7 arc-min

Output shaft supported by dual radial ball bearing system. The two bearings straddle the planet carrier

Easy mounting to a wide variety of servomotors Quick Connect[®] motor adaptation system includes a clamshell style servo coupling and piloted adapter flange.



CONTENTS

Rating Table	65
Performance Table	66
Outline Dimensions67-	71
Product Sizing & Selection72-	73

Motor Code HPN **J6** D ŧ..... Size tion Batic Output Configuration nnut Co 11 4, 5, 7, 10, 15, 20,25, 30, 35, 40, 45, 50 Z: Input side bearing with This code represents the motor HarmonicPlanetary double non- contact J6: Shaft output with key and 14 shields mounting configuration. Please contact us for a unique part HPN center tapped hole 20 А D: Input side bearing with double contact seals. (Recommended for output shaft up orientation.) J8: Shaft output with center 3, 4, 5, 7, 10, 15, 20, **Hiah Toraue** number based on the motor you 32 25, 30, 35, 40, 45, 50 tapped hole are using. 40

Gearhead Construction



Rating Table

										Table 065-
	Number of Stages	Ratio	Rated Torque L10 *1	Rated Torque L50 *1	Limit for Repeated Peak Torque *2	Limit for Momentary Torque *3	Max. Average Input Speed*4	Max. Input Speed* ⁵	Allowable Radial Load ^{*6}	Allowable Axial Load*7
	of oragoo		Nm	Nm	Nm	Nm	rpm	rpm	N	N
		4	9	14	14	40	-			
	1	5	9	14	16	40	-			
		7 10	8	11 9	<u>11</u> 9	40 40	-			
		15	11	18	24	40	-			
11		20	13	22	24	40	3,000	10,000	480	640
		25	13	20	24	40	0,000	10,000	400	040
	2	30	15	25	26	40	-			
		35 40	16 17	26	26 26	40 40	-			
		40	17	26 26	26	40	-			
		50	18	26	26	40	-			
		3	14	22	25	89				
		4	18	28	50	110				
	1	5	18	29	50	107	-			
	·	7	20	30	37	100	-			
		10 15	14 21	18 30	<u>18</u> 43	79 97	-			
14		20	23	30	43	100	3,000	6,000	840	900
14		25	26	30	38	102		-,		
		30	26	40	48	98	-			
	2	35	28	40	49	99				
		40	29	30	38	100				
		45	29	30	38	100	-			
		50 3	20	26 51	26 74	94 226				
		4	31 50	80	130	226	-			
		5	52	80	149	256	-			
	1	7	55	80	113	256				
		10	41	54	54	216				
		15	59	80	129	256				
20		20	66	80	147	256	3,000	6,000	1,800	2,200
		25	72	80	114	256	-			
	2	30 35	72 79	80 80	139 112	250 256	-			
		40	80	80	112	256	-			
		45	80	80	112	256	-			
		50	58	75	75	216				
		3	94	153	254	625				
	1	4	122	198	376	625	-			
		5 7	127	200 200	376 376	625 625	-			
		10	135 128	185	185	625	-			
		15	146	200	376	625				
32		20	162	200	376	625	3,000	6,000	3,900	3,800
		25	176	200	376	625				
	2	30	179	250	376	625	-			
		35	193	250	376	625	-			
		40 45	200 206	300 300	376 376	625 625	-			
		45 50	193	251	251	625	-			
		3	272	440	752	1137				
		4	287	460	752	1265]			
	1	5	298	480	752	1265				
		7	317	510	752	829	4			
		10	302	480	509	829				
40		15 20	342 380	530 600	752 752	1265 1265	3,000	6,000	5,500	5,400
40		20	413	650	752	1205	5,555	2,300	0,000	0,400
		30	421	650	752	1265	1			
	2	35	452	700	752	1127]			
		40	468	700	752	1127				
		45	484	700	752	1127				
	1	50	432	562	562	1162				

*1: Rated torque is based on life of 20,000 hours at max average input speed. *2: The limit for torque during start and stop cycles.

*3: The limit for torque during emergency stops or from external shock loads. Always operate below this value.

*4: Max value of average input rotational speed during operation.

*5: Maximum instantaneous input speed. *6. The load at which the output bearing will have 20,000 hour life at 100 rpm output speed (Axial load = 0 and radial load point is in the center of the output shaft)

*7. The load at which the output bearing will have 20,000 hour life at 100 rpm output speed (Radial load = 0 and axial load point is in the center of the output shaft)

Performance

-						Table 065-2								Table 065-3
Size	Number of	Ratio	Backlash	Noise*1	Torsional	Stiffness		Size	Number of	Ratio	Backlash	Noise*1	Torsional	Stiffness
0120	Stages		arc min	dB	kgfm/arc-min	X100N•m/rad		0120	Stages		arc min	dB	kgfm/arc-min	X100N•m/rad
	1	4 5 7 10	< 5						1	3 4 5 7	< 5			
11	2	15 20 25 30 35 40 45 50	< 7	< 56	0.060	20		32	2	10 15 20 25 30 35 40 45	< 7	< 63	2.8	940
	1	3 4 5 7 10	< 5						1	50 3 4 5 7	< 5			
14	2	15 20 25 30 35 40 45 50	< 7	< 58	0.27	93		40	2	10 15 20 25 30 35 40 45	< 7	< 65	4.2	1430
	1	3 4 5 7 10	< 5				L			50				
20	2	15 20 25 30 35 40 45	<7	< 60	0.77	260								

*1: The above noise values are reference values.

50

66 HarmonicPlanetary"& HarmonicDrive * Gearheads





Dimension Table

											(Unit	: mm) Table 067-1
	A (F	17)*1	B*1	C	;*1	F (I	H7)*1	(G*1	H*1	к	Maga(//g)*2
	Min.	Max.	Max.	Min.	Max.	Min.	Max.	Min.	Max.		r.	Mass(kg)*2
Single Stage	20	55	3	30	75	5	9	18	29	93.5	27.5	0.44
Two Stage	20		0		75	5	5	10	23	113	47	0.57

Refer to the confirmation drawing for detailed dimensions. Dimensions of typical products are shown. Please contact us for other mounting options if the configurations

Shown above are not suitable for your particular motor.
May vary depending on motor interface dimensions.
The mass will vary slightly depending on the ratio and on the inside diameter of the input shaft coupling.
Tapped hole for motor mounting screw.

Moment of Inertia

wome	nt of in	iertia										(10 ⁻⁴ kgm ²)	Table 067-2
HPN-11A	Ratio Coupling	4	5	7	10	15	20	25	30	35	40	45	50
THE NETTA	1	0.04	0.04	0.04	0.04	0.04	0.04	0.04	0.04	0.04	0.04	0.04	0.04

HPN-14A Outline Dimensions



(Note) The dimension tolerances that are not specified vary depending on the manufacturing method. Please check the confirmation drawing or contact us for dimension tolerances not shown on the drawing above. Output shaft configuration shown is J6 (with a key and center tapped hole). J8 configuration has no key.

Dimension Table

(Unit: mm) Table 068-1

	Elenge	Coupling	A (H	H7)*1	B*1	C	;*1	F (H	17)*1	G	*1	L1*1	K	Maga/(rg)*2
	Flange	Coupling	Min.	Max.	Max.	Min.	Max	Min.	Max.	Min.	Max.	"	ĸ	Mass(kg)*2
Single Stage	2	2	35	75	5	40	100	6	14	18	28	117	36	0.95
Two Stage		3	- 35	75	5	40	100	0	14	10	20	142	61	1.3

Refer to the confirmation drawing for detailed dimensions. Dimensions of typical products are shown. Please contact us for other mounting options if the configurations shown above are not suitable for your particular motor. *1 May vary depending on motor interface dimensions. *2 The mass will vary slightly depending on the ratio and on the inside diameter of the input shaft coupling. *3 Tapped hole for motor mounting screw.

Moment of Inertia

IVI	ome	nt of in	iertia										(1	0 ⁻⁴ kgm²)	Table 068-2
ЦВ	'N-14A	Ratio Coupling	3	4	5	7	10	15	20	25	30	35	40	45	50
	N=1+/	1	0.26	0.23	0.21	0.20	0.20	0.20	0.20	0.20	0.19	0.19	0.19	0.19	0.19

HPN-20A Outline Dimensions



Dimension Table

(Unit: mm) Table 069-1

	Elango	Coupling	A (F	I7)*1	B*1	C	;*1	F (H	17)*1	G	*1	H*1	V	Mass(kg)*2
	Flange	Coupling	Min.	Max.	Max.	Min.	Max.	Min.	Max.	Min.	Max.		N	Mass(kg) -
Single Stage	1	1	50	85	7	55	115	13.5	25.4	26	47	166.5	52	3
Two Stage	'		50	65	l '	55	115	10.0	20.4	24.5	41	188.2	73.7	3.7
Single Stage		1	50	125	7	60	155	13.5	25.4	44	65	184.5	52	3.7
Two Stage	2	•	50	125	· '	00	155	13.5	20.4	42.5	59	206.2	73.7	4.7
Single Stage	3	2	35	75	7	40	100	9.5	14.2	25.5	40.5	160	52	2.6
Two Stage	4	3	35	75	5	40	100	6	14.2	18	28	175	73.7	3.2

Refer to the confirmation drawing for detailed dimensions. Dimensions of typical products are shown. Please contact us for other mounting options if the configurations shown above are not suitable for your particular motor. *1 May vary depending on motor interface dimensions.

2 The mass will vary slightly depending on the ratio and on the inside diameter of the input shaft coupling.
 3 Tapped hole for motor mounting screw.

Moment of Inertia

													U Kgili)	Table 069-2
	Ratio Coupling	3	4	5	7	10	15	20	25	30	35	40	45	50
HPN-20A	1	1.20	1.00	0.92	0.87	0.86	0.86	0.87	0.87	0.85	0.86	0.85	0.85	0.85
111 11-204	2	0.53	0.36	0.29	0.24	0.21	-	-	-	-	-	-	-	-
	3	-	-	-	-	-	0.23	0.22	0.22	0.20	0.21	0.20	0.20	0.20

(10⁻⁴ kgm²) Table 069-2

HPN-32A Outline Dimensions



(Note) The dimension tolerances that are not specified vary depending on the manufacturing method. Please check the confirmation drawing or contact us for dimension tolerances not shown on the drawing above. Output shaft configuration shown is J6 (with a key and center tapped hole). J8 configuration has no key.

Dimension Table

l

M 13.5 25.4 25 51 58.5 6.6 7 55 115 200 1 1 50 85 15.5 28 42 64 217.5 58.5 7.7 Single Stage 2 2 55 125 7 65 155 3 3 65 215 6.5 75 260 21.5 41 47 85 238.5 58.5 9.3 13.5 25.4 26 46.5 246.5 107.2 7.9 4 4 50 85 7 55 115 Two Stage 13.5 25.4 44 65 264.5 107.2 9.1 5 4 50 125 7 60 155 9.5 14.2 25.5 40.5 240.5 107.2 7.2 35 75 7 40 100 6 5

Refer to the confirmation drawing for detailed dimensions. Dimensions of typical products are shown. Please contact us for other mounting options if the configurations shown above are not suitable for your particular motor. *1 May vary depending on motor interface dimensions.

*2 The mass will vary slightly depending on the ratio and on the inside diameter of the input shaft coupling. *3 Tapped hole for motor mounting screw.

Moment of Inertia

												(1	0 ⁻⁴ kgm ²)	Table 070-2
	Ratio Coupling	3	4	5	7	10	15	20	25	30	35	40	45	50
	1	2.3	1.7	1.5	1.3	1.2	-	-	-	-	-	-	-	-
HPN-32A	2	4.9	3.6	3.1	2.7	2.5	-	-	-	-	-	-	-	-
HFN-32A	3	6.9	5.7	5.2	4.8	4.7	-	-	-	-	-	-	-	-
	4	-	-	-	-	-	1.1	1.0	1.0	0.91	0.93	0.91	0.89	0.91
	5	-	-	-	-	-	0.48	0.40	0.42	0.28	0.30	0.28	0.25	0.25

(Unit: mm) Table 070-1

HPN-40A Outline Dimensions



Dimension Table

												(Unit: m	m) Table 071-1
	Flange	Coupling	A (ŀ	17)*1	B*1	С	;*1	F (ŀ	17)*1	G	*1	H*1	к	Mass(kg)*2
	Tiange	Couping	Min.	Max.	Max.	Min.	Max.	Min.	Max.	Min.	Max.		N	Widss(kg) -
	1	1	70	215	6.5	80	260	27.5	41	34.5	71.5	295.5	81	17
Single Stage	2	2	70	175	6.5	80	225	42	42	39	104.5	328.5	81	16
	3	3	70	125	7	80	155	15.5	18.5	42	71.5	295.5	81	13
Two Stage	4	4	55	125	7	65	155	15.5	28.5	42	63.5	332	126	17
Two Stage	5	5	65	215	6.5	75	260	21.5	41	47	84.5	353	126	18

Refer to the confirmation drawing for detailed dimensions. Dimensions of typical products are shown. Please contact us for other mounting options if the configurations shown above are not The other command of advances of the command of a section of the command of the command

Moment of Inertia

Mome	ent of Ir	iertia											(10 ⁻⁴ kgm ²)	Table 071-2
	Ratio Coupling	3	4	5	7	10	15	20	25	30	35	40	45	50
	1	13.6	8.8	7.0	5.9	5.1	-	-	-	-	-	-	-	-
HPN-40A	2	15.8	11.0	9.2	7.7	6.9	-	-	-	-	-	-	-	-
	3	12.2	7.4	5.6	4.1	3.3	-	-	-	-	-	-	-	-
	4	-	-	-	-	-	3.9	3.6	3.8	2.8	3.0	2.9	2.8	2.8
	5	-	-	-	-	-	5.9	5.6	5.9	4.9	5.3	5.1	5.0	4.9

(Linit: mm) Table 071-1

Sizing & Selection

To fully utilize the excellent performance of the HPN HarmonicPlanetary® gearheads, check your operating conditions and, using the flowchart, select the appropriate size gear for your application.

Check your operating conditions against the following application motion profile and select a suitable size based on the flowchart shown on the right. Also, compare any application radial and axial loads supported by the gearhead output shaft to the allowable values in the ratings table to ensure an adequate output bearing service life.

Application motion profile

Review the application motion profile. Check the specifications shown in the figure below.



Obtain the value of each applica Load torque Time Output rotational speed	tion motion profile T1 to Tn (Nm) t1 to tn (sec) n1 to nn (rpm)
Normal operation pattern Starting (Acceleration) Steady operation (constant velocity) Stopping (deceleration) Dwell	T1, t1, n1 T2, t2, n2 T3, t3, n3 T4, t4, n4
Maximum rotational speed Max. output rotational speed Max. input rotational speed (Restricted by motors)	no max \ge n1 to nn ni max n1×R to nn×R R: Reduction ratio
Emergency stop torque When impact torque is applied	Ts
Required life	L10 = L (hours)

Flowchart for selecting a size

Please use the flowchart shown below for selecting a size. Operating conditions must not exceed the performance ratings.



If any of the following conditions exist, please consider selecting the next larger speed reducer, reduce the operating loads or reduce the operating speed. If this cannot be done, please contact Harmonic Drive LLC. Exercise caution especially when the duty cycle is close to continuous operation.

i) Actual average load torque (Tav) > rated torque or

ii) Actual average input rotational speed (ni av) > max average input speed (nr),

iii) Gearhead housing temperature > 70°C.

Example of size selection

Load torque Time Output rotational speed	Tn (Nm) tn (sec) nn (rpm)			Maximum rotational speed Max. output rotational speed Max. input rotational speed	no max = 120 rpm ni max = 5,000 rpm (Restricted by motors)
Normal operation patter Starting (acceleration) Steady operation	ern T1 = 70 Nm,	t1 = 0.3 sec,	n1 = 60 rpm	Emergency stop torque When impact torque is applied	Ts = 180 Nm
(constant velocity) Stopping (deceleration) Dwell	T2 = 18 Nm, T3 = 35 Nm, T4 = 0 Nm,	$t_2 = 3 \text{ sec},$ $t_3 = 0.4 \text{ sec},$ $t_4 = 5 \text{ sec},$	n2 = 120 rpm n3 = 60 rpm n4 = 0 rpm	Required life L ₅₀ = 30,000 (hours)	



for Servo

High-Performance Gear

HPN-A Series

HarmonicPlanetary®

HarmonicDrive®

Technical Information

Efficiency	134
Output Bearing Specifications and Checking Procedure	153
Input Bearing Specifications and Checking Procedure	157

Product Handling

Assembly	159
Mechanical Tolerances	162
Lubrication	163
Warranty, Disposal	165
Safety	166
The rated value and performance vary depending on the product series.	

Be sure to check the usage conditions and refer to the items conforming to the related product.

Efficiency

In general, the efficiency of a speed reducer depends on the reduction ratio, input rotational speed, load torque, temperature and lubrication condition. The efficiency of each series under the following measurement conditions is plotted in the graphs on the next page. The values in the graph are average values.

Measurement condition

	Table 134-1
Input rotational speed	HPGP / HPG / HPF / HPN:3000rpm CSG-GH / CSF-GH:Indicated on each efficiency graph.
Ambient temperature	25°C
Lubricant	Use standard lubricant for each model. (See pages 163- 164 for details.)

Efficiency compensated for low temperature

Calculate the efficiency at an ambient temperature of 25°C or less by multiplying the efficiency at 25°C by the low-temperature efficiency correction value. Obtain values corresponding to an ambient temperature and to an input torque (TRi*) from the following graphs when calculating the low-temperature efficiency correction value.



CSG-GH CSF-GH



* TRi is an input torque corresponding to output torque at 25°C.



HPGP





--- Gearhead (standard item)



T_{Ri} Input torque corresponding to output torque



······ Gearhead with D bearing (double sealed)





*1 Only one line is shown because the difference between the gearhead and a bearing assembled on the input side is small.



Efficiency %





HamonicPlanetary*&HarmonicDrive* Technical Information / Handling Explanat

*3 Only one line is shown because the difference between the gearhead and a bearing assembled on the input side is small.

Reduction ratio = 12



10

0

0

0.2

0.4

TRi Input torque corresponding to output torque

Input torque Nm

Reduction ratio = 45

0.6

0.8

1

HammonicPlanetan*& HarmonicDrive* nical Information / Handling Explanation



10

0

0

0.5

--- Gearhead (standard item)

Reduction ratio = 21

1 Input torque Nm 1.5

2

----- Gearhead with D bearing (double sealed)



Size 32 Gearhead & Input Shaft Unit HPG



*1 Only one line is shown because the difference between the gearhead and a bearing assembled on the input side is small.

25

10





100

*3 Only one line is shown because the difference between the gearhead and a bearing assembled on the input side is small.









15 20

Input torque Nm

25 30 35 40





Input torque Nm

T_{Ri} Input torque corresponding to output torque

30

20

10 0

0 5 10

40



Reduction ratio = 20

Reduction ratio = 40

Input torque Nm

Reduction ratio = 50





Reduction ratio = 25

T_{Ri} Input torque corresponding to output torque

Input torque Nm

Efficiency %



0



0







HamonicPlanetary*&HarmonicDrive* Technical Information / Handling Explar





Output Shaft Bearing Load Limits

HPN Series Output Shaft Load Limits are plotted below.

HPN uses deep groove ball bearings to support the output shaft. Please use the curve on the graph for the appropriate load coefficient (fw) that represents the expected operating condition.



Output shaft speed - 100 rpm, bearing life is based on 20,000 hours. The load-point is based on shaft center of radial load and axial load.

Output Bearing Specifications and Checking Procedure

HPGP, HPG, HPG Helical, CSF-GH, CSG-GH, HPF, and HPG-U1 are equipped with cross roller bearings. A precision cross roller bearing supports the external load (output flange).

Check the maximum load, moment load, life of the bearing and static safety coefficient to maximize performance.

Checking procedure



Maximum moment load (M*max*) \leq Permissible moment (Mc)

.

Calculate the life and check it.

(2) Checking the life

Calculate the average radial load (Frav) and the average axial load (Faav).

, , ,

(3) Checking the static safety coefficient Calculate the static equivalent radial load coefficient (Po).

Check the static safety coefficient. (fs)

Calculate the radial load coefficient (X)

and the axial load coefficient (Y).

Specification of output bearing

HPGP/HPG Series Tables 153-1, -2 and -3 indicate the cross roller bearing specifications for in-line, right angle and input shaft gears.

										Table 153-1
	Pitch circle	Offset amount		Basic ra	ted load		Allowable mor	ment load Mc*3	Moment sti	ffness Km*4
Size	dp	R	Basic dynamic	c load rating C*1	Basic static Ic	ad rating Co*2	Nm	Kashara	×10₄	Kgfm/
	m	m	N	kgf	N	kgf		Kgfm	Nm/rad	arc min
11	0.0275	0.006	3116	318	4087	417	9.50	0.97	0.88	0.26
14	0.0405	0.011	5110	521	7060	720	32.3	3.30	3.0	0.90
20	0.064	0.0115	10600	1082	17300	1765	183	18.7	16.8	5.0
32	0.085	0.014	20500	2092	32800	3347	452	46.1	42.1	12.5
50	0.123	0.019	41600	4245	76000	7755	1076	110	100	29.7
65	0.170	0.023	90600	9245	148000	15102	3900	398	364	108

			Table 153-2
Size	Reduction	Allowable radial load*5	Allowable axial load *5
Size	ratio	Ν	Ν
	5	280	430
	(9)	340	510
11	21	440	660
	37	520	780
	45	550	830
	(3)	400	600
	5	470	700
11 600	600	890	
14	15	650	980
	21	720	1080
	33	830	1240
	45	910	1360
	(3)	840	1250
	5	980	1460
	11	1240	1850
20		2030	
	21	1510	2250
	33	1729	2580
	45	1890	2830

	15 [.]	102	3	900	398		364	108		
								Table 153-3		
Size F		Reduc	Reduction		able radial load*	5	Allowable	e axial load *5		
		rati			N			Ν		
(;		(3)			1630		2	430		
32	5			1900		2	830			
		11			2410		3	590		
	32	15			2640		3	940		
		21			2920		4	360		
		33			3340		4	990		
		45			3670		5480			
		(3)	(3)		3700			5570		
		5		4350			6490			
		11		5500			8220			
	50	15		6050			9030			
		21		6690			9	980		
		33		7660			11400			
		45		8400			12500			
		4			8860		13	3200		
		5		9470			14100			
		12			12300		18	3300		
		15			13100		19	600		
	65	20			14300		21	400		
		25			15300		22	2900		
		(40)		17600		26	300		
		(50)		18900		28200			

* The ratio specified in parentheses is for the HPG Series.

* The ratio	specified in	parentheses	is for the	e HPG Series

[Note: Table 153-1, -2 and -3 Table 154-1 and -2]

- *1 The basic dynamic load rating means a certain static radial load so that the basic dynamic rated life of the roller bearing is a million rotations.
- *2 The basic static load rating means a static load that gives a certain level of contact stress (4kN/mm²) in the center of the contact area between rolling element receiving the maximum load and orbit.
- *3 The allowable moment load is a maximum moment load applied to the bearing. Within the allowable range, basic performance is maintained and the bearing is operable. Check the bearing life based on the calculations shown on the next page.
- *4 The value of the moment stiffness is the average value.

*5 The allowable radial load and allowable axial load are the values that satisfy the life of a speed reducer when a pure radial load or an axial load applies to the main bearing. (Lr + R = 0 mm for radial load and La = 0 mm for axial load) If a compound load applies, refer to the calculations shown on the next page.

CSG-GH/CSF-GH Series

Table 154-1 indicates the specifications for cross roller bearing.

		-										Table 154-1
	Pitch circle	Offset amount	Basic load rating				Allowable Moment stiffness Km*4			Allowable	Allowable	
Size	dp	R		lynamic ting C*1	Basic load rati		moment	load Mc*3	×10 ⁴	kgfm/	radial load*5	axial load*5
	m	m	N	kgf	Ν	kgf	Nm	kgfm	Nm/rad	arc min	N	Ν
14	0.0405	0.011	5110	521	7060	720	27	2.76	3.0	0.89	732	1093
20	0.064	0.0115	10600	1082	17300	1765	145	14.8	17	5.0	1519	2267
32	0.085	0.014	20500	2092	32800	3347	258	26.3	42	12	2938	4385
45	0.123	0.019	41600	4245	76000	7755	797	81.3	100	30	5962	8899
65	0.170	0.0225	81600	8327	149000	15204	2156	220	323	96	11693	17454

HPF Series Table 154-2 indicates the specifications for cross roller bearing.

Table 154-2 Allowable ment load Mc* Allowab axial loa Basic dynamic load rating C*1 kgf kgf 37.9 25 0.085 0.0153 11400 20300 2071 11.3 1163 410 41.8 1330 1990 32 0.1115 0.015 22500 2296 39900 4071 932 95 86.1 25.7 2640 3940

[Note: Table 153-1, -2 and -3 Table 154-1 and -2]

*1 The basic dynamic load rating means a certain static radial load so that the basic dynamic rated life of the roller bearing is a million rotations.
*2 The basic static load rating means a static load that gives a certain level of contact stress (4kN/mm²) in the center of the contact area

between rolling element receiving the maximum load and orbit.

*3 The allowable moment load is a maximum moment load applied to the bearing. Within the allowable range, basic performance is maintained and the bearing is operable. Check the bearing life based on the calculations shown on the next page.

*4 The value of the moment stiffness is the average value.

*5 The allowable radial load and allowable axial load are the values that satisfy the life of a speed reducer when a pure radial load or an axial load applies to the main bearing. (Lr + R = 0 mm for radial load and La = 0 mm for axial load) If a compound load applies, refer to the calculations shown on the next page.

How to calculate the maximum moment load

HPGP	HPG	CSG-GH
CSF-GH	HPF	

Maximum moment load (Mmax) is obtained as follows. Make sure that $M_{max} \leq Mc$.

	M <i>max</i> =Fr	<i>max</i> (L	r+R)+Fa <i>max</i> La
Fr <i>max</i>	Max. radial load	N (kgf)	See Fig. 155-1.
Fa <i>max</i>	Max. axial load	N (kgf)	See Fig. 155-1.
Lr, La	_	m	See Fig. 155-1.
	0		See Fig. 155-1.
R	Offset amount	m	See "Output Bearing Specifications" of each series, p.153 & 154

How to calculate the radial and the axial load coefficient

HPGP	HPG	CSG-GH
CSF-GH	HPF	

The radial load coefficient (X) and the axial load coefficient (Y)

	For	mula		Х	Y
Fr a	Faa v+2(Frav(Lr+R)	1	0.45		
Fr <i>a</i>	Fa. v+2(Fr <i>av</i> (Lr+R)	0.67	0.67		
Fr av	Average radial load	N (kgf)	See "How to calculate the av	verage load below."	
ur	÷	(
Fa <i>av</i>	Average axial load	N (kgf)	See "How to calculate the av	erage load below."	
Fa <i>av</i> Lr, La	Average axial load	N (kgf) m	See "How to calculate the av See Fig. 155-1.	erage load below."	
	Average axial load Offset amount				

How to calculate the average load (Average radial load, average axial load, average output speed)

HPGP HPG CSG-GH CSF-GH HPF

If the radial load and the axial load fluctuate, they should be converted into the average load to check the life of the cross roller bearing.



Figure 155-1

External load influence diagram



How to calculate the life HPGP HPG CSG-GH CSF-GH

HPF

Calculate the life of the cross roller bearing using Formula 156-1. You can obtain the dynamic equivalent load (Pc) using Formula 156-2.

	. 106	. (Formula 156-1 C \ ^{10/3}
	$L_{10} = \frac{10^6}{60 \times N}$	× (- av (1	fw·Pc)
L10	Life	hour	
	Ave. output speed	rpm	See "How to calculate the ave, load
Nav	Ave. output speed		
N <i>av</i> C	Basic dynamic load rating	N (kgf)	See "Output Bearing Specs."

Load coefficient	Table 156-1
Load status	fw
During smooth operation without impact or vibration	1 to 1.2
During normal operation	1.2 to 1.5
During operation with impact or vibration	1.5 to 3

$Pc = X \cdot \left(Frav + \frac{2(Frav(Lr+R) + Faav \cdot La)}{dp} \right) + Y \cdot Faav$						
Fr <i>av</i>	Average radial load	N (kgf)	- See "How to calculate the ave. load."			
Fa <i>av</i>	Average axial load	N (kgf)				
dp	Pitch Circle of roller	m	See "Output Bearing Specs."			
Х	Radial load coefficient	-	See "How to calculate the radial load			
Y	Axial load coefficient	-	coefficient and the axial load coefficient."			
Lr, La	_	m	See Figure 155-1. See "External load influence diagram."			
R	Offset amount	m	See Figure 155-1. See "External load influence diagram" and "Output Bearing Specs" of each series.			

How to calculate the life during oscillating motion	HPGP	HPG	CSG-GH
Calculate the life of the cross roller bearing during oscillating	g motion by F	ormula 156-	-3.

HPF Figure 156-1

CSF-GH



When it is used for a long time while the rotation speed of the output shaft is in the ultra-low operation range (0.02rpm or less), the lubrication of the bearing Note becomes insufficient, resulting in deterioration of the bearing or increased load in the output side. When using it in the ultra-low operation range, contact us.

How to calculate the static safety coefficient HPGP

HPG

CSG-GH CSF-GH HPF

In general, the basic static load rating (Co) is considered to be the permissible limit of the static equivalent load. However, obtain the limit based on the operating and required conditions. Calculate the static safety coefficient (fs) of the cross roller bearing using Formula 156-4.

General values under the operating condition are shown in Table 156-2. You can calculate the static equivalent load (Po) using Formula 156-5.

≧1.5

				Form	nula 156-4
	Co	Basic static load	N (kgf)	See "Output Bearing Sp	becs."
	Ро	Static equivalent load	N (kgf)	See Formula 156-5.	
Sta	tic sa	afety coefficient			Table 156-2
		Load status		fs	
	When I	high precision is required		≧3	
	When i	mpact or vibration is exp	ected	≧2	

			Formula 156
	Po=Fr <i>max</i> +	2M max dp +0.4	44Fa <i>max</i>
Fr max	Max. radial load	N (kgf)	
Fa <i>max</i>	Max. axial load	N (kgf)	See "How to calculate the max, moment
	Max, moment load	Nm (kgfm)	load."
M <i>max</i>		(0)	

Under normal operating condition

Input Bearing Specifications and Checking Procedure

Check the maximum load and life of the bearing on the input side if the reducer is an HPG input shaft unit or an HPF hollow shaft unit.



Specification of input bearing

Specifica	ation of input bearing	HPG		Table 157-1
		Basic loa	ad rating	
Size	Basic dynamic	load rating Cr	Basic static lo	bad rating Cor
	N	kgf	N	kgf
11	2700	275	1270	129
14	5800	590	3150	320
20	9700	990	5600	570
32	22500	2300	14800	1510
50	35500	3600	25100	2560
65	51000	5200	39500	4050

	Table 157						
Size	Allowable mo	ment load Mc	Allowable axial load Fac*1		Allowable rac	dial load Frc *2	
Size	Nm	kgfm	Ν	kgf	Ν	kgf	
11	0.16	0.016	245	25	20.6	2.1	
14	6.3	0.64	657	67	500	51	
20	13.5	1.38	1206	123	902	92	
32	44.4	4.53	3285	335	1970	201	
50	96.9	9.88	5540	565	3226	329	
65	210	21.4	8600	878	5267	537	

Table 157-3

Specification of input shaft bearing

HPF

Size	Basic dynami	namic load rating Cr Basic static load rating Cor		bad rating Cor
	N	kgf	N	kgf
25	14500	1480	10100	1030
32	29700	3030	20100	2050

	Table 157-4							
Size	Allowable mo	ment load Mc	Allowable axi	al load Fac*1	Allowable rac	dial load Frc *3		
Size	Nm	kgfm	Ν	kgf	Ν	kgf		
25	10	1.02	1538	157	522	53.2		
32	19	1.93	3263	333	966	98.5		

(Note: Table 157-2 and 157-4)

*1 The allowable axial load is the value of an axial load applied along the axis of rotation.

*2 The allowable radial load of HPG series is the value of a radial load applied at the mid-point of the input shaft.

*3 The allowable radial load of HPG series is the value of a radial load applied to the point of 20 mm from the shaft edge (input flange edge).

Teble 157.0

Calculating maximum moment load ON input shaft

The maximum moment load (Mimax) is calculated as follows. Check that the following formulas are established in all circumstances:

			Formula 158
I	Mi <i>max</i> =Fri <i>max</i> ∙Lr	∙i+Fai <i>max</i> ∙L	ai
Fri <i>max</i>	Max. radial load	N (kgf)	See Fig. 158-1
Fri <i>max</i> Fai <i>max</i>	Max. radial load Max. axial load	N (kgf) N (kgf)	See Fig. 158-1 See Fig. 158-1

Mi $max \leq Mc$ (Allowable moment load) Fai $max \leq Fac$ (Allowable axial load)



How to calculate average load (Average moment load, average axial load, average input speed)

HPG HPF

If moment load and axial load fluctuate, they should be converted into the average load to check the life of the bearing.



How to calculate the average moment load (Miav) Formula 158-2 $Mi av = \sqrt[3]{\frac{n_1 t_1(|Mi_1|)^3 + n_2 t_2(|Mi_2|)^3 \cdots n_n t_n(|Mi_n|)^3}{n_1 t_1 + n_2 t_2 + \cdots + n_n t_n}}$

How to calculate the average axial load (Faiav)

Fai
$$av = \sqrt[3]{\frac{n_1 t_1 (|Fai_1|)^3 + n_2 t_2 (|Fai_2|)^3 \cdots n_n t_n (|Fai_n|)^3}{n_1 t_1 + n_2 t_2 + \cdots + n_n t_n}}}$$

How to calculate the average input speed (Niav)

Niav = $\frac{n_1 t_1 + n_2 t_2 + \dots + n_n t_n}{t_1 + t_2 + \dots + t_n}$

Formula 158-4

Formula 158-3

Calculating life of input bearing

Calculate the bearing life according to Calculation Formula 158-5 and check the life.



Dynamic ec	uivalent load HPG	Table 158-1
Size	Pci	
11	0.444 × Mi av + 1.426	6 × Fai <i>av</i>
14	0.137 × Mi av + 1.232	2 × Fai <i>av</i>
20	0.109 × Mi av + 1.232	2 × Fai <i>av</i>
32	0.071 × Mi av + 1.232	2 × Fai <i>av</i>
50	0.053 × Mi av + 1.232	2 × Fai <i>av</i>
65	0.041 × Mi av + 1.232	2 × Fai <i>av</i>

Dynamic eq	uivalent load	HPF	Table 158-2
Size		Pci	
25	121 × Mi	<i>av</i> + 2.7 × Fai <i>av</i>	
32	106 × Mi	<i>av</i> + 2.7 × Fai <i>av</i>	

Miav Average moment load Nm (kgfm) Faiav Average axial load N (kgf) See Formula 158-2 See Formula 158-3

Assembly

Assemble and mount your gearhead in accordance with these instructions to achieve the best performance. Be sure to use the recommended bolts and use a torque wrench to achieve the proper tightening torques as recommended in tables below.



To properly mount the motor to the gearhead, follow the procedure outlined below, refer to figure 159-1

(1) Turn the input shaft coupling and align the bolt head with the rubber cap hole.

(2)

With the speed reducer in an upright position as illustrated in the figure below, slowly insert the motor shaft into the coupling of speed reducer. Slide the motor shaft without letting it drop down. If the speed reducer cannot be positioned upright, slowly insert the motor shaft into the coupling of speed reducer, then tighten the motor bolts evenly until the motor flange and gearhead flange are in full contact. Exercise care to avoid tilting the motor when inserting it into the gear head.

(3) Tighten the input shaft coupling bolt to the recommended torque specified in the table below. The bolt(s) or screw(s) is (are) already inserted into the input coupling when delivered. Check the bolt size on the confirmation drawing provided.

I	Bolt tightening torque Table 159-										
	Bolt size		M3	M4	M5	M6	M8	M10	M12		
	Tightening torque	Nm	2.0	4.5	9.0	15.3	37.2	73.5	128		
		kgfm	0.20	0.46	0.92	1.56	3.8	7.5	13.1		

Caution: Always tighten the bolts to the tightening torque specified in the table above. If the bolt is not tightened to the torque value recommended slippage of the motor shaft in the shaft coupling may occur. The bolt size will vary depending on the size of the gear and the shaft diameter of the mounted motor. Check the bolt size on the confirmation drawing provided.

Two setscrews need to be tightened on size 11. See the outline dimensions on page 22 (HPGP) and page 34 (HPG standard) and page 46 (HPG helical). Tighten the screws to the tightening torque specified below.

		Table 159-2
Bolt size	M3	
Tinhtonian tour	Nm	0.69
Tightening torque	kgfm	0.07

(4) Fasten the motor to the gearhead flange with bolts.

Bolt* tightening torque

boit ugitterning	lorque								Table 159-3
Bolt size		M2.5	M3	M4	M5	M6	M8	M10	M12
Tightoning torque	Nm	0.59	1.4	3.2	6.3	10.7	26.1	51.5	89.9
Tightening torque	kgfm	0.06	0.14	0.32	0.64	1.09	2.66	5.25	9.17

*Recommended bolt: JIS B 1176 Hexagon socket head bolt, Strength: JIS B 1051 12.9 or higher

Caution: Be sure to tighten the bolts to the tightening torques specified in the table.

(5) Insert the rubber cap provided. This completes the assembly. (Size 11: Fasten screws with a gasket in two places)

Figure 159-1



Speed reducer assembly

НРСР НРС С

CSG-GH CSF-GH

HPF

HPN

T-1-1- 400 4

Some right angle gearhead models weigh as much as 60 kg. No thread for an eyebolt is provided because the mounting orientation varies depending on the customer's needs. When mounting the reducer, hoist it using a sling paying extreme attention to safety.

When assembling gearheads into your equipment, check the flatness of your mounting surface and look for any burrs on tapped holes. Then fasten the flange (Part A in the diagram below) using appropriate bolts.

												Table 160-		
0.		HPN					HPGP / HPG / CSG-GH / CSF-GH						HPF	
Size		11	14	20	32	40	11	14	20	32	45/50	65	25	32
Number of bolts		4	4	4	4	4	4	4	4	4	4	4	12	12
Bolt size		M3	M5	M6	M8	M10	M3	M5	M8	M10	M12	M16	M4	M5
Mounting PCD	mm	50	70	100	130	165	46	70	105	135	190	260	127	157
Tishtanin a tanawa	Nm	1.4	6.3	10.7	26.1	51.5	1.4	6.3	26.1	51.5	103	255	4.5	9.0
Tightening torque	kgfm	0.14	0.64	1.09	2.66	5.26	0.14	0.64	2.66	5.25	10.5	26.0	0.46	0.92
Transmission torque	Nm	27.9	110	223	528	1063	26.3	110	428	868	2030	5180	531	1060
	kgfm	2.85	11.3	22.8	53.9	108.5	2.69	11.3	43.6	88.6	207	528	54.2	108

* Recommended bolts: JIS B 1176 "Hexagon socket head bolts." Strength classification 12.9 or higher in JIS B 1051.

Mounting the load to the output flange

Follow the specifications in the table below when mounting the load onto the output flange.



Output flange mounting specifications

Bolt* tightening torque for a	output fl	ange (Part B in th	e Figure 160-1)	HPGP			Table 160-2
Size		11	14	20	32	50	65
Number of bolts		4	8	8	8	8	8
Bolt size		M4	M4	M6	M8	M12	M16
Mounting PCD	mm	18	30	45	60	90	120
Tightening torque	Nm	4.5	4.5	15.3	37.2	128.4	319
ngniening torque	kgfm	0.46	0.46	1.56	3.8	13.1	32.5
Transmission torque	Nm	25.3	84	286	697	2407	5972
Tanomission lorque	kgfm	2.58	8.6	29.2	71.2	245	609

* Recommended bolts: JIS B 1176 "Hexagon socket head bolts." Strength classification 12.9 or higher in JIS B 1051.

Bolt* tightening torque for output flange (Part B in the Figure 160-1)

Table 160										
Size		11	14	20	32	50	65			
Number of bolts		3	6	6	6	14	6			
Bolt size		M4	M4	M6	M8	M8	M16			
Mounting PCD	mm	18	30	45	60	100	120			
Tightening torque	Nm	4.5	4.5	15.3	37.2	37.2	319			
nghiening torque	kgfm	0.46	0.46	1.56	3.8	3.80	32.5			
Transmission torque	Nm	19.0	63	215	524	2036	4480			
Tanomission lorque	kgfm	1.9	6.5	21.9	53.4	207.8	457			

HPG

* Recommended bolts: JIS B 1176 "Hexagon socket head bolts." Strength classification 12.9 or higher in JIS B 1051.

Assembly Instructions

Mounting the load to the output flange

Bolt* tightening torque for	CSG-GH		Table 161-1			
Size		14	20	32	45	65
Number of bolts		8	8	10	10	10
Bolt size		M4	M6	M8	M12	M16
Mounting PCD	mm	30	45	60	94	120
Tightening torque	Nm	4.5	15.3	37	128	319
	kgfm	0.46	1.56	3.8	3.1	32.5
Transmission torque	Nm	84	287	867	3067	7477
Transmission torque	kgfm	8.6	29.3	88.5	313	763

Bolt* tightening torque for	output	flange (Part B in	Figure 160-1)	CSF-GH		Table 161-2
Size		14	20	32	45	65
Number of bolts		6	6	6	16	8
Bolt size		M4	M6	M8	M8	M16
Mounting PCD	mm	30	45	60	100	120
Tightening torque	Nm	4.5	15.3	37.2	37.2	319
	kgfm	0.46	1.56	3.80	3.80	32.5
Transmission torque	Nm	63	215	524	2326	5981
Tanomission lorque	kgfm	6.5	21.9	53.4	237	610

Table 161-3

Bolt* tightening torque for output flange HPF (Part B in Figure 160-1)

			Table 161-3
Size		25	32
Number of bolts		12	12
Bolt size		M4	M5
Mounting PCD m		77	100
Tightening torque	Nm	4.5	9.0
nghiening torque	kgfm	0.46	0.92
Transmission torque	Nm	322	675
Transmission torque	kgfm	32.9	68.9

* Recommended bolts: JIS B 1176 "Hexagon socket head bolts." Strength classification 12.9 or higher in JIS B 1051.

Gearheads with an output shaft HPN HPG HPGP CSG-GH CSF-GH

HPF

Do not subject the output shaft to any impact when mounting a pulley, pinion or other parts. An impact to the the output bearing may affect the speed reducer precision and may cause reduced life or failure.

Mechanical Tolerances

Superior mechanical precision is achieved by integrating the output flange with a high-precision cross roller bearing as a single component. The mechanical tolerances of the output shaft and mounting flange are specified below.





Table 162-4

(T.I.R.* Unit: mm)

0.050

0.050

	Axial runout of output flange a	Radial runout of output flange pilot or output shaft b	Perpendicularity of mounting flange c	Concentricity of mounting flange d
11	0.020	0.030	0.050	0.040
14	0.020	0.040	0.060	0.050
20	0.020	0.040	0.060	0.050
32	0.020	0.040	0.060	0.050
52	0.020	0.040	0.000	0.030

50 0.020 0.040 0.060 0.050 65 0.040 0.060 0.090 0.080					Table 162-2
65 0.040 0.060 0.090 0.080	50	0.020		0.060	0.050
	65	0.040	0.060	0.090	0.080

CSG-GH	CSF-GH
--------	--------

Ta					
45	0.020	0.040	0.060	0.050	
65	0.020	0.040	0.060	0.050	

HPF			
25	0.020	0.040	0.060
32	0.020	0.040	0.060

* T.I.R.: Total indicator reading

Lubrication

Prevention of grease and oil leakage

(Common to all models)

- Only use the recommended greases.
- Provisions for proper sealing to prevent grease leakage are incorporated into the gearheads. However, please note that some leakage
 may occur depending on the application or operating condition. Discuss other sealing options with our applications engineers.
- When mounting the gearhead horizontally, position the gearhead so that the rubber cap in the adapter flange is facing upwards.

(CSG/CSF-GH Series)

Contact us when using HarmonicDrive® CSG/CSF-GH series with the output shaft facing downward (motor on top) at a constant load or rotating continuously in one direction.

Sealing

(Common to all models)

- Provisions for proper sealing to prevent grease leakage from the input shaft are incorporated into the gearhead.
- A double lip Teflon oil seal is used for the output shaft (HPGP/HPG uses a single lip seal), gaskets or o-rings are used on all mating surfaces, and non contact shielded bearings are used for the motor shaft coupling (Double sealed bearings (D type) are available as an option*). On the CSG/CSF-GH series, non contact shielded bearing and a Teflon oil seal with a spring is used.
- Material and surface: Gearbox: Aluminum, corrosion protected roller bearing steel, carbon steel (output shaft). Adapter flange: (if provided by Harmonic Drive) high-strength aluminum or carbon steel. Screws: black phosphate. The ambient environment should not subject any corrosive agents to the above mentioned material. The product provides protection class IP 54 under the provision that corrosion from the ambient atmosphere (condensation, liquids or gases) at the running surface of the output shaft seal is prevented. If necessary, the adapter flange can be sealed by means of a surface seal (e.g. Loctite 515).
- * D type: Bearing with a rubber contact seal on both sides

(HPG/HPGP/HPF/HPN Series)

- Using the double sealed bearing (D type) for the HPGP/HPG series gearhead will result in a slightly lower efficiency compared to the standard product.
- An oil seal without a spring is used ON the input side of HPG series with an input shaft (HPG-1U) and HPF series hollow shaft reducer. An option for an oil seal with a spring is available for improved seal reliability, however, the efficiency will be slightly lower (available for HPF and HPG series for sizes 14 and larger).
- Do not remove the screw plug and seal cap of the HPG series right angle gearhead. Removing them may cause leakage of grease or affect the precision of the gear.

Standard Lubricants

HPG/HPGP/HPF/HPN Series

The standard lubrication for the HPG/HPGP/HPF/HPN series gearheads is grease.

- All gearheads are lubricated at the factory prior to shipment and additional application of grease during assembly is not required. The gearheads are lubricated for the life of the gear and do not require re-lubrication.
- High efficiency is achieved through the unique planetary gear design and grease selection.

Lubricants

Harmonic Grease SK-2 (HPGP/HPG-14 Manufacturer: Harmonic Drive Systems In		EPNOC Grease AP (N) 2 (HPGP/HPG-11, 50, 65 / HPF-25, 32) Manufacturer: Nippon Oil Co.			
Thickening agent: Lithium soap	Consistency: 265 to 295 at 25°C Dropping point: 198°C Color: Green	Base oil: Refined mineral oil Thickening agent: Lithium soap Additive: Extreme pressure agent and other Standard: NLGI No. 2	Consistency: 282 at 25°C Dropping point: 200°C Color: Light brown		
PYRONOC UNIVERSAL 00 (HPG right angle gearhead/HPN) Manufacturer: Nippon Oil Co.		MULTEMP AC-P (HPG-X-R) Manufacturer: KYODO YUSHI CO, LTD			
Thickening agent: Urea	Consistency: 420 at 25°C Dropping point: 250°C or higher Color: Light yellow	Base oil: Composite hydrocarbon oil and diester Thickening agent: Lithium soap Additive: Extreme pressure	Standard: NLGI No. 2 Consistency: 280 at 25°C Dropping point: 200°C Color: Black viscose		

Ambient operating temperature range: -10°C to +40°C

The lubricant may deteriorate if the ambient operating temperature is outside of recommended operating range. Please contact our sales office or distributor for operation outside of the ambient operating temperature range.

and others

The temperature rise of the gear depends upon the operating cycle, ambient temperature and heat conduction and radiation based on the customers installation of the gear. A housing surface temperature of 70°C is the maximum allowable limit.

CSG-GH/CSF-GH Series

The standard lubrication for the CGS-GH / CSF-GH series gearheads is grease. All gearheads are lubricated at the factory prior to shipment and additional application of grease during assembly is not necessary.

Lubricants

Harmonic Grease SK-1A (Size 20, 32, 45, 65) Manufacturer: Harmonic Drive Systems Inc. This grease has been developed exclusively for HarmonicDrive® gears and is excellent in durability and efficiency compared to commercial general-purpose grease.

Base oil: Refined mineral oil Thickening Agent: Lithium soap Additive: Extreme pressure agent and other Standard: NLGI No. 2 Consistency: 265 to 295 at 25°C Dropping point: 197°C Color: Yellow

Harmonic Grease SK-2 (Size 14) Manufacturer: Harmonic Drive Systems Inc. This grease has been developed exclusively for smaller sized HarmonicDrive® gears and allows smooth wave generator rotation.

Base oil: Refined mineral oil Thickening Agent: Lithium soap Additive: Extreme pressure agent and other Standard: NLGI No. 2 Consistency: 265 to 295 at 25°C Dropping point: 198°C Color: Green

Ambient operating temperature range: -10°C to +40°C

The lubricant may deteriorate if the ambient operating temperature is outside the recommended temperature range. Please contact our sales office or distributor for operation outside of the ambient operating temperature range. The temperature rise of the gear depends upon the operating cycle, ambient temperature and heat conduction and radiation based on the customers installation of the gear. A housing surface temperature of 70°C is the maximum allowable limit.

When to change the grease

The life of the Harmonic Drive® gear is affected by the grease performance. The grease performance varies with temperature and deteriorates at elevated temperatures. Therefore, the grease will need to be changed sooner than usual when operating at higher temperatures. The graph on the right indicates when to change the grease based upon the temperature (when the average load torque is less than or equal to the rated output torque at 2000 rpm). Also, using the formula below, you can calculate when to change the grease when the average load torque exceeds the rated output torque (at 2000 rpm).

Formula to calculate the grease change interval when the average load torque exceeds the rated torque Formula 164-1

LGT = LGTn ×
$$\left(\frac{\text{Tr}}{\text{Tay}}\right)^3$$

1	Formula symbols Table 164-					
	L _{gt}	Grease change interval when Tav > Tr	Input rotations			
	L _{GTn}	Grease change interval when Tav <= Tr	Input rotations	See Graph 164-1		
	Tr	Output torque at 2000 rpm	Nm, kgfm	See the "Rating table" on pages 87 & 97.		
	Tav	Average load torque	Nm, kgfm	Calculation formula: See page 111.		



LGTn (when the average load torque is equal to or less than the rated output torque at 2000 rpm)



* L10 Life of wave generator bearing

F	Reference values f	or grease	refill amou	int		Table 164-2
		14	20	32	45	65
	Amount: g	0.8	3.2	6.6	11.6	78.6

Precautions when changing the grease

Strictly observe the following instructions when changing the grease to avoid problems such as grease leakage or increase in running torque.

- •Note that the amount of grease listed in Table 164-2 is the amount used to lubricate the gear at assembly. This should be used as a reference. Do not exceed this amount when re-greasing the gearhead.
- Remove grease from the gearhead and refill it with the same quantity. The adverse effects listed above normally do not occur until the gear has been re-greased 2 times. When re-greasing 3 times or more, it is essential to remove grease (using air pressure or other means) before re-lubricating with the same amount of grease that was removed.

Warranty

Please contact us or visit our website at www.harmonicdrive.net for warranty details for your specific product.

All efforts have been made to ensure that the information in this catalog is complete and accurate. However, Harmonic Drive LLC is not liable for any errors, omissions or inaccuracies in the reported data. Harmonic Drive LLC reserves the right to change the product specifications, for any reason, without prior notice. For complete details please refer to our current Terms and Conditions posted on our website.

Disposal

When disposing of the product, disassemble it and sort the component parts by material type and dispose of the parts as industrial waste in accordance with the applicable laws and regulations. The component part materials can be classified into three categories.

(1) Rubber parts: Oil seals, seal packings, rubber caps, seals of shielded bearings on input side (D type only)

- (2) Aluminum parts: Housings, motor flanges
- (3) Steel parts: Other parts

Trademark

HarmonicDrive® is a registered trademark of Harmonic Drive LLC. HarmonicPlanetary® is a registered trademark of Harmonic Drive LLC.

Safety

Warning : Means that improper use or handling could result in a risk of death or serious injury.

Caution : Means that improper use or handling could result in personal injury or damage to property.

Application Restrictions

This product cannot be used for the following applications:

- * Space flight hardware * Aircraft equipment
- * Vacuum environments * Automotive equipment

* Equipment for transport of humans

- * Nuclear power equipment* Personal recreation equipment
- * Personal recreation equipment
 * Equipment for use in a special environment
- * Equipment that directly works on human bodies
 * Medical equipment

* Equipment and apparatus used in residential dwellings

Please consult Harmonic Drive LLC beforehand if intending to use one of our product for the aforementioned applications.

Fail-safe devices that prevent an accident must be designed into the equipment when the products are used in any equipment that could result in personal injury or damage to property in the event of product failure.



Handlin	g Lubricant		
A warning	Precautions on handling lubricants Lubricant in the eye can cause inflammation. Wear protective glasses to prevent if from getting in your eye. Lubricant coming in contact with the skin can cause inflammation. Wear protective gloves when you handle the lubricant to prevent it from contacting your skin. Do not ingest (to avoid diarrhea and vomiting). Use caution when opening the container. There may be sharp edges that can cut your hand. Wear protective gloves. Keep lubricant out of reach of children.	Caution	 Disposal of waste oil and containers Follow all applicable laws regarding waste disposal. Contact your distributor if you are unsure how to properly dispose of the material. Do not apply pressure to an empty container. The container may explode. Do not weld, heat, drill or cut the container. This may cause residual oil to ignite or cause an explosion.
	 First-aid Inhalation: Remove exposed person to fresh air if adverse effects are observed. Ingestion: Seek immediate medical attention and do not induce vomiting 	Caution	 Storage Tightly seal the container after use. Store in a cool, dry, dark place. Keep away from open flames and high temperatures.
Warning	 unless directed by medical personnel. Eyes: Flush immediately with water for at least 15 minutes. Get immediate medical attention. Skin: Wash with soap and water. Get medical attention if irritation develops. 	Dispos	al Please dispose of as industrial waste. Please dispose of the products as industrial waste when their useful life is over.

Major Applications of Our Products



Metal Working Machines



Processing Machine Tools



Measurement, Analytical and Test Systems



Medical Equipment



Telescopes

Source: National observatory of Inter-University Research Institute Corporation



Energy

Courtesy of Haliiburton/Sperry Drilling Services



Crating and Packaging Machines



Communication Equipment



Space Flight Hardware Rover image created by Dan Maas, copyrighted to Cornell and provided courtesy NASA/ JPL-Caltech.



Robots



Glass and Ceramic Manufacturing Systems



Source: Honda Motor Co., Ltd.





Flat Panel Display

Manufacturing Equip.



Optical Equipment

Manufacturing Machines



Aerospace

Machine Tools





Experts in Precision Motion Control



Other Products

HarmonicDrive® Gearing

HarmonicDrive® speed reducer delivers precise motion control by utilizing the strain wave gearing principle.



Rotary Actuators

High-torque actuators combine performance matched servomotors with HarmonicDrive® gears to deliver excellent dynamic control characteristics.



Linear Actuators

Compact linear actuators combine a precision lead screw and HarmonicDrive® gear. Our versatile actuators deliver both ultra precise positioning and high torque.



CSF Mini Gearheads

CSF mini gearheads provide high positioning accuracy in a super-compact package.



Harmonic Drive LLC

Boston US Headquarters 247 Lynnfield Street Peabody, MA 01960

New York Sales Office 100 Motor Parkway Suite 116 Hauppauge, NY 11788

California Sales Office 333 W. San Carlos Street Suite 1070 San Jose, CA 95110

Chicago Sales Office 137 N. Oak Park Ave., Suite 410 Oak Park, IL 60301

T: 800.921.3332 T: 978.532.1800 F: 978.532.9406

www.HarmonicDrive.net

Group Companies

Harmonic Drive Systems, Inc. 6-25-3 Minami-Ohi, Shinagawa-ku Tokyo 141-0013, Japan

Harmonic Drive AG Hoenbergstrasse, 14, D-6555 Limburg/Lahn Germany

Harmonic Drive®, Harmonic Gearhead®, Harmonic Planetary® and Quick Connect® are registered trademarks of Harmonic Drive LLC. All other trademarks are property of their respective owners.



